

Driver Damage Disputes

If a driver desires to dispute or get clarification of damage:

- Notify Clerk
- Proceed to the chassis inspections area
 1. Explain to the mechanic your issue
 2. Request a manager present
 - a. Mechanic shall always contact a MCT Manager for damage disputes

Terminal has final word on severity of damage however driver does have the option of taking the container back off terminal.